
Foam Storage Tanks


Tank Accessories | Bladder Tank Level Indicator Gauge



Related Documents	None avaiable
Red Arrow	Reference value (non-binding)
Black Arrow	Operating value
Numbers from 0-6	Metres of water column (hydrostatic head pressure)
Part Number	**IDR10006**

See bladder tank manual for usage instructions.





Ex- = 2 m



Empty tank



1/3 full tank



2/3 tank

Note: This document contains basic product information only. Information, photos and drawings are not contractually binding. In all cases, the manufacturer's full technical documentation (see "Related Documents" above) remains the reference document. Note that certificates, test reports and approvals may be published in the OEM name.

The contents of this publication are subject to modifications without notice. All rights reserved

© K.C. Antincendi S.r.l. | Via Pavia 76 | 27042 Bressana Bottarone (PV) | Italy | info@kcantincendi.com